

VsionAir Guitar Jig

Packing List for Guitar Neck & Body Jig

Tools Required for Assembly: 10mm Spanner to Socket Wrench, Cross Head Screwdriver

Assembly Drawing Reference	Qty	Description
1		VAX-FRM-300 300mm VsionAir V Frame
	1	300mm V Frame
2		VAX-HA VAX Jig Height Adjuster Assembly
	1	Height Adjuster Collet
	2	M6 x 10mm Countersunk Screw
	2	M6 Half Nut
3		VAX-180 180 Degree Angle Adjuster Bracket Assembly
	2	180 Degree Angle Bracket
	8	M6 x 10mm Flange Screw
	8	M6 Half Nut
	4	M6 x 16mm Hex Head Bolt
	4	M6 Washers
	2	M6 Nylon Lock Nut
	2	M6 Locking Knob
4		VAX-FRM-500 VsionAir V Frame
	1	500mm V Frame
5		V Bracket Assembly
	2	V Bracket
	8	M6 x 10mm Flange Screw
	8	M6 Half Nut
6		Vertical Support Beam V Frame
	1	250mm V Frame
7		360 Degree Angle Lock Adjuster Assembly
	1	Angle Lock Adjuster
	1	Vsionair Locking Handle
	2	M6 x 40mm Allen Head Bolt
	2	M6 Nylon Lock Nut
	2	M6 x 10mm Countersunk Screw
	2	M6 Half Nut
8		Length Adjuster Assembly
	2	Height Adjuster Collet
	4	M6 x 10mm Countersunk Screw
	4	M6 Half Nut

9		Guitar Neck & Body Support Beam V Frame
	2	300mm V Frame
10		Guitar Neck & Body Support Bracket Assembly
	2	Guitar Neck/Body Brackets
	4	M6 x 12mm Countersunk Screw
	4	M6 Half Nut

If assistance is required, please contact your supplier